



Digital Bidet System

BA-08




BA-08

SPECIFICATION

Operating Time	Rear Cleansing	1 minute Maximum 0.2gal/min(0.7l/min), Self-cleaning nozzle
	Bidet	1 minute Maximum 0.2gal/min(0.7l/min), Self-cleaning nozzle
Seat temperature	Off	Room Temperature: 68 °F (20°C)
	On	Low : 91.4 °F (33°C) Medium : 96.8 °F (36°C) High : 102.2 °F (39°C)
	Temperature Control	3 Levels
Warm Air Dryer	Operating Time	2 minutes
	Life Cycle	4 months (2.5 tons/month, for under 0.5 NTU of turbidity)
MF Filter	Dimension	(L) 136 * (?) 48mm
	Power Consumption	850 W (Max)
Operating Noise		37.0 ~ 48.0
Dimension (Width x Height x Depth)		20.7 x 5.6 x 19.7inch
Net Weight		6.2kg(13.7lb)

STRUCTURE



REMOTE CONTROL



FEATURES



Wide Water Stream

User can select the expand level of cleansing water. User can choose the level of the water spray between strong and gentle as they wish with Bidet.



Air + Water Stream

There is softer feeling with strong cleansing power in the water stream with air.



Nozzle Position

The nozzle position can be adjusted to wherever the user wants.



Ergonomic seat

Optimized seat for human body provides you the comfort you need even if you were seating for a long time.



Remote control

The controlling part of the product is specially made in the form of remote control for convenience.



Auto cleansing

You can run the 'rear cleansing' function and 'air dryer' function conveniently with just one key.



Self-testing

The LED in the main body will flash when there is a problem in the product and the buzzer will ring to let you know that there is a problem.

(The water is heated when the LED flashes without the buzzer ringing.)



Move

During the rear cleansing or front cleansing select the 'move' function to move the nozzle forward and backward for much cleaner cleansing.



Nozzle self-cleaning

The cleaning water will be automatically sprayed to nozzle for about 5 seconds after the rear cleansing or front cleansing and it will always be clean.



Nano silver ceramic filter for water purification

MF filter for the water purification is adopted for continuous cleaning with purified water.



Twin nozzle

It is very hygienic, since the anal cleansing nozzle and female bidet nozzle are separated.



Auto Power Saving Mode

If the sensor do not detect the human body and there is no control on the key for 30 minutes, the product will switch to auto power saving mode and the water and seat temperature will be re-set to 'low'. The LED in the main body will be switched off. (If anyone sits down or control the key, LED in the main body will be turned on and the water and seat temperature will be re-set to the last mode.

- Auto power saving mode is set as the initial setting.
- Setting/cancelling the auto power saving mode*
- 1) Please turn the power of the remote control on and plug the power cord in while pressing the 'Rear cleansing' button. (You will hear a buzzing sound)
- 2) Please press the 'Rear cleansing' button to set up the auto power saving mode.
 - The auto power saving mode is cancelled when the buzzer rings once. (clang)
 - The auto power saving mode is set when the buzzer rings twice. (clang clang)
- 3) Complete the setting by pressing 'air dryer' key, after choosing the auto power saving mode. (The buzzer will ring three times-clang clang clang)



Seat Locking Mode

The rear cleansing/front cleansing/air dryer/auto cleansing function will not be operated, if the sensor does not sense human body through the seating sensor.

- The seat locking mode is not set as the initial setting. The rear cleansing/front cleansing/air dryer/auto cleansing function will be working regardless of the seating status.

- Setting/Cancelling the seat locking mode*
- 1) Please turn the power of the remote control on and plug the power cord in while pressing the 'rear cleansing' button. (You will hear a buzzing sound)
- 2) Please press the 'front cleansing' button to set up the auto power saving mode.
 - The auto power saving mode is cancelled when the buzzer rings once. (clang)
 - The auto power saving mode is set when the buzzer rings twice. (clang clang)
- 3) Complete the setting by pressing 'air dryer' key, after choosing the auto power saving mode. (The buzzer will ring three times-clang clang clang)



Mute Mode

There will be no sound coming out when keys are pressed. -The mute mode is not set as the initial setting. You will notice the status of the functions with the buzzer.

- Setting/Cancelling the mute mode*
- 1) Please turn the power of the remote control on and plug the power cord in while pressing the 'rear cleansing' button. (You will hear a buzzing sound)
- 2) Please press the 'stop' button to set up the auto power saving mode.
 - The auto power saving mode is cancelled when the buzzer rings once. (clang)
 - The auto power saving mode is set when the buzzer rings twice. (clang clang)
- 3) Complete the setting by pressing 'air dryer' key, after choosing the auto power saving mode. (The buzzer will ring three times-clang clang clang)



Nozzle Cleaning

The nozzle will be extended to the maximum length for nozzle cleaning.

Hi-Tech Sweet Water Technologies Pvt. Ltd.

An ISO 9001-2000 Certified and N.S.I.C. - C.S.P.O. Registered Company

Call Centre No.: +91 98980 47820, +91 98980 22557 • National Toll Free No.: 1800 2331 365

email: info@hitechro.net • Visit us at www.hitechro.net